

SCM-PD-PLUS with SCM-10-EXT-CC Underwater Lights



HOW TO OPERATE

Power On/Off

Press Button Change Color or Color Rotation Scheme

Press and Hold Button for 2 seconds

Step through modes: Solid Color / Fade / Strobe

RECOMMENDED WIRE GAUGES

Scan the QR Code or click [here](#) to view our recommended wire gauge chart.



1 MODE DIP SWITCH SETTINGS (from left to right counting up)

	1	2	3
↑	Network Enable	Chase Mode On	Extended Color Range Enabled
↓	Network Disable	Chase Mode Off	Extended Color Range Disabled

■ Indicates recommended settings for this installation

2 LIGHT ENABLE DIP SWITCH SETTINGS (from left to right counting up)

	1	2	3	4	5	6
↑	Light 1 Enable	Light 2 Enable	Light 3 Enable	Light 4 Enable	Light 5 Enable	Light 6 Enable
↓	Light 1 Disable	Light 2 Disable	Light 3 Disable	Light 4 Disable	Light 5 Disable	Light 6 Disable

■ Indicates recommended settings for this installation

