


SEAFLO®

SWITCH PANEL INSTURCTION MANUAL






SFSP-01




SFSP-02



SFSP-015-01

SFSP-015-02

INSTRUCTION TIP:



Model	SFSP-01	SFSP-02	SFSP-015-01	SFSP-015-02
Volts	12V & 24V	12V & 24V	12V & 24V	12V & 24V
Fuel	***	***	15 A	15 A

WARNING

- 1. Keep all wire connections above water level. Wires must be joined with butt connectors and a marine grade sealant to prevent wire corrosion.
- 2. Install red wires to positive terminal only and black to negative terminal only.
- 3. Disconnect power from the system before working on the unit to avoid personal injury, damage to the surrounding environment and/or damage to the unit.
- 4. Max working draw: 15A.